

## Connections | GC ferrules SilTite® FingerTite

The smart alternative. One nut, one ferrule, all systems.

Part number	Part description and detail
073630	SilTite FingerTite Ferrule 0.4 mm Hole
073631	SilTite FingerTite Ferrule 0.5 mm Hole
073632	SilTite FingerTite Ferrule 0.7 mm Hole
073633	SilTite FingerTite Blanking Ferrule
073636	SilTite FingerTite Female Nut
073625	SilTite FingerTite Generic Starter Kit
0736100	SilTite FingerTite Starter Kit (5 x Female Nuts, 10 x 0.4 mm Hole Ferrules, 1 x Measuring Tool)
0736105	SilTite FingerTite Starter Kit (5 x Female Nuts, 10 x 0.5 mm Hole Ferrules, 1 x Measuring Tool)
<b>Agilent</b>	
073610	SilTite FingerTite Agilent INJ / FID Starter Kit
073611	SilTite FingerTite Agilent Capillary / FID Starter Kit
073612	SilTite FingerTite Agilent INJ / MS Starter Kit
07361053	SilTite FingerTite Agilent INJ / FID Starter Kit for Use with 0.53 mm ID Columns
07361054	SilTite FingerTite Agilent Injector Starter Kit for Use with 0.53 mm ID Columns (10 x 0.7 mm Ferrules)
0736101	SilTite FingerTite Agilent Capillary Adaptor
0736102	SilTite FingerTite Agilent MS Adaptor
0736103	SilTite FingerTite Agilent FID Adaptor (Includes 2 Graphite Vespel FID Ferrules)
0736104	SilTite FingerTite Agilent Injector Adaptor (Includes 2 Base Seals) Also Suits Thermo 1300 Injector
073640	SilTite FingerTite Agilent MS Adaptor
<b>ATAS</b>	
073651	SilTite FingerTite ATAS OPTIC INJ Starter Kit
<b>Bruker/Varian</b>	
073618	SilTite FingerTite Bruker/Varian INJ / FID Starter Kit
073619	SilTite FingerTite Bruker/Varian INJ / MS Starter Kit (Not for 220, 1200, 2000, or 4000 MS Systems)
<b>Shimadzu</b>	
073628	SilTite FingerTite Shimadzu 17A INJ / FID Starter Kit
073629	SilTite FingerTite Shimadzu 17A INJ / MS Starter Kit
073620	SilTite FingerTite Shimadzu 2010 INJ / FID Starter Kit
07362053	SilTite FingerTite Shimadzu 2010 INJ / FID Starter Kit for Use with 0.53 mm ID Columns
073621	SilTite FingerTite Shimadzu 2010 INJ / MS Starter Kit
<b>Thermo Scientific</b>	
073614	SilTite FingerTite Thermo INJ (Not for 1300 Injector) / FID Starter Kit
073615	SilTite FingerTite Thermo INJ (Not for 1300 Injector) / ISQ Starter Kit
073616	SilTite FingerTite Thermo INJ (Not for 1300 Injector) / DSQ/DSQII Starter Kit
<b>PerkinElmer</b>	
073622	SilTite FingerTite PerkinElmer INJ / FID Starter Kit
073623	SilTite FingerTite PerkinElmer INJ / MS Starter Kit

For more information about this product visit [www.trajanscimed.com](http://www.trajanscimed.com) or contact [techsupport@trajanscimed.com](mailto:techsupport@trajanscimed.com)